HABITAT CENTRAL 340

EC Motor



Two year replacement warranty

Premium centralised Heat Recovery unit - introduce fresh, filtered air into your home.





Key Features

Regenerating Efficiency Up to 92%

Current (A) 1.6

Max Power (w) 180

Extract Filter G4

Supply Filter G4 (Optional F8 & H13)

Filter Replacement Alert: Yes
Weight (kg) 37.7

5 Speeds

 300 m3/hr @ 100 Pa
 180w

 250 m3/hr @ 50 Pa
 125w


 210 m3/hr @ 50 Pa
 70w


 150 m3/hr @ 50 Pa
 50w

 100 m3/hr @ 50 Pa
 30w

Suitable for RS485 Modbus for SMART Home

Dimensions (mm)





fanco



Unit can be mounted horizontally or vertically

Operation Modes

Manual

Away Mode

Fan speed reduced to low level to maintain air quality




Automatic

Automate based on schedule and/or sensor detection.

IAQ Control

Indoor Air Quality Control - Unit can dynamically adjust based on real time data from sensors

Product Structure & Internal Sensors



Included as Standard

Relative Humidity & Temp Sensors

Relative Humidity & Temperature sensors within each chamber ensure that the unit can operate automatically based on these variables.

Optional Accessory

CO2. VOC & PM2.5 Sensor

This optional sensor is installed inside the HRV unit, and ensures comprehensive indoor air quality control.

Control Options



Standard

Wall Control

Can be used on its own or paired with WIFI

3.5" Wall Mounted Controller

Provides full control, but does not allow for parameter and setting adjustment of timer, boost duration and all sensors (see below).



Premium

Wall Control

Can be used on its own or paired with WIFI

7" Wall Mounted Controller

Premium controller is required if you wish to adjust parameters and settings of timer, boost duration and all sensors.

Pair this controller with the WIFI module to access external sensors, app control & full setting customisation.



WIFI

Module

Can be used on its own, controlled via app or paired with wall control

WIFI module allows control of unit via app

External Sensors require WIFI module

Setting Customisation

The Premium wall control is required to configure settings beyond factory default.

	[<u>25</u> 5]	(600) <u>F</u> (800) <u>F</u> (800) 25 1 2 2 4 4 2	(((0))
Control Type	Standard	Premium	WIFI Module
External Sensors	/	✓ 🕏	/
Bypass Temperature	✓	✓ 🕏	/
Defrost Temperature	/	✓ 🕏	/
Boost Duration	/	✓ 🕏	/
Timer	/	✓ 🕏	/
Away Mode	/	✓ 🕏	/
Filter Reset	✓ 🚉	✓ 幸	✓ 🚔



Settings can be configured

External Sensors

External wireless sensors can also be purchased as an optional accessory. These are designed to be installed specifically within rooms for even greater levels of control.

3 Options ((O))



WIFI Module required for all external sensors

Option 1





Relative Humidity & **Temperature**

Option 2









Option 3








Relative Humidity, Temperature & PM2.5

Up to 8 external sensors can be connected per unit.

Installation Example

Option 1 sensors in wet areas such as bathroom or kitchen, ensure automation based on temperature and humidity levels

Option 2 or Option 3 sensors are typically installed in bedrooms or other living areas, in order to control levels of CO2 or PM2.5 particles, in addition to relative humidity and temperature.



How does it work?

A heat recovery unit (HRV) is designed to introduce fresh, filtered air into the home, whilst also removing stale, moisture laden air.

As the warm, moisture laden air is extracted from the kitchen and bathrooms, it passes through the heat exchanger, which accumulates heat during this process.

Simultaneously, fresh air from the outside is drawn into the system, passing through the heat exchanger. This ensures it is warm before entering the living space. The air also passes through a filter (see exploded product view below).

This cycle is critical to maintaining indoor air quality.

